




Sony Ericsson Vivaz (U5) Digitizer Replacement

Written By: ZFix




INTRODUCTION

How to change / replace Touch Screen / Digitizer - **Sony Ericsson Vivaz U5**, also known as Sony Ericsson Kurara!

Video Guide

[video: http://www.youtube.com/watch?v=zTJxE_O5KAE]

Step 1 — Change / Replace Touch Screen



- First remove battery, sim card and memory card. You must remove seven screws.

Step 2



- Now remove this part.

Step 3



- This baseboards are stucked with a double-sided tape.

Step 4




- Remove the Touch Screen! To be more easy, heat it with hot air before doing so!

Step 5



- Now is the time for the new Touch Screen.

Step 6



- Test, assembling and... that is all.
- .
- [Please SUBSCRIBE to my channel ツ](#)

To reassemble your device, follow these instructions in reverse order.

This document was last generated on 2017-06-17 02:31:27 AM.